




# Expand FlagStand XL Set-up Instruction (water bags)




1. Open the carry bag and remove the base




2. Open the base




3. Press down on the middle to lock the base, listen for the "click"




4. Depending on the location of a water source: mount the empty bags and fill with water or carry the bags to a water source, fill and then attach the bags to the pegs on the frame.




5. Mounting the graphic rings to the graphic and slide the rings onto the telescopic pole



6. Slide the top pole into the pole pocket at the top of the graphic and attach it to the telescopic pole with the screw on cap



7. Insert the telescopic pole into the base and tighten the retaining knob.



8. Extend each telescopic section until it "clicks" into the locking position and the stand is at the desired height